







Voltage/Hertz/Amperage Meter Options



DRPDSO-2460-3P
add DRAM364 meter panel



DRPD23F-3P
add DRMOEM6-366C meter panel



Meter option panels including Voltage, Hertz and Amperage for measuring X&Y (single phase), X, Y & Z (three phase) with/without Neutral. VM panels (Volts, Hertz) and AM panels (Amps, Volts, Hertz) are added to the top of distro.

Meters are hardwired and engage when power is applied. Ring transformers are used for all panel distros.

EM panels combine a 3ph meter set (Amperage, Voltage, Hertz) with breakered convenience outlets. U-Ground receptacles available in 3ph colors.



2U DRDO-EM6-366C



2U DRDO-AM3-262



2U DRDO-AM3-363

Ring Current Transformer



2U DRDO-AM3-263



2U DRDO-AM3-364